CHAUVIN ARNOUX
ENERGY

The first time you power up the device, the following page is displayed.

n.o. Ct.FSA

For preliminary setup, press the SET button for at least **4 sec**

1 Enter the CT value

The CT value is the ratio of the primary value divided by the CT secondary value

Example:
CT 100/5A => CT ratio = 20

SETUP
Ct 10000

Press

Modify the value with

Confirm with

Press ⬆

2 Enter the FSA value

The FSA value is the value of the CT secondary

Example:
CT 100/1A => FSA = 1

SETUP
FSA 5

Press

Modify the value with

Confirm with

Press ⬆

**3** Select the wiring mode

3.3.2 3-wire balanced 3-phase, 2 CTs
3.3.3 3-wire unbalanced 3-phase, 3 CTs
3.4.3 4-wire unbalanced 3-phase, 3 CTs

SETUP
Wir 3.4.3

Press

Modify the value with

Confirm with

Press for **3 sec**

4 Save and exit

SETUP
SAVE? y

Confirm with