



When the instrument is first powered up, it scrolls through the following pages.



To set up the preliminary configuration, press the SET button for at least 3sec.

1

Choose the wiring mode



Press



The mode will flash

**3.4.3**=three-phase, 4 wires, 3 currents  
**3.3.2**=three-phase, 3 wires, 2 currents  
**1ph**=single-phase

Modify the mode using



Confirm with



Appuyer 2 fois sur



2

Enter the required FSA




Press



The value will flash

**Available values:**  
500 A / 4 kA / 20 kA.

Modify the value using



Confirm with



**The FSA corresponds to the current range**  
For  $I \leq 500$  A, use the **500 A range**  
For  $500 \text{ A} \leq I \leq 4 \text{ kA}$ , use the **4 kA range**  
For  $4 \text{ kA} \leq I \leq 20 \text{ kA}$ , use the **20 kA range**

3

Save and exit

For 3sec, press



Confirm with

